


SUBURBAN TRACTOR



BODY WORK AND TRIM ASSEMBLY

Models 3018G AND 3114G


REF. NO.	PART NO.	DESCRIPTION	QTY. REQ.	REF. NO.	PART NO.	DESCRIPTION	QTY. REQ.
1	1747835	Seat (3114) (1)	1	38	1186389	Flange Lock Nut 1/4-20	12
	1752915	Seat (3114) (2)	1	39	1742493BDG	Grille Cap	2
	1747834	Seat (3018) (1)	1	40	1100069	Hex Hd. Screw 1/4-20 x 1	2
	1755949	Seat (3018) (2)	1	41	1742494	Grille (1)	1
2	1186130	Rd. Hd. Sq. Neck Screw 3/8-16 x 1-1/4 (1)	1		1755948BDG	Grille (2)	1
3	1743434	Seat Support Assembly (1)	1	42	1743566	Side Cover Guide (1)	4
4	1733960	Compression Spring (1)	1		1753912	Side Cover Guide (2)	4
5	1735125	Nut & Washer Assembly (1)	1	43	1756629	Pop Rivet 1/8 x 1/4	8
6	1107383	Flat Washer 3/8	2	44	1743554BDG	L.H. Side Cover	1
7	1734269	Knob	2		1743553BDG	R.H. Side Cover	1
8	1735265	Pivot Block (1)	2	45	1744065	Sealing Block	2
9	1107382	Flat Washer 5/16 (1)	2	46	1115815	Phil. Hd. Machine Screw #10-24 x 5/8	4
10	1100799	Hex Screw 5/16-18 x 1-1/2 (1)	2	47	1727127	Rubber Latch	2
11	1750543	Rear Fender (1)	1	48	1727126	Clip	2
	1756154BOW	Rear Fender (2)	1	49	1185985	Keps Nut #10-24	2
12	1747663	Hood Decal (1)	1	50	1744067	Sealing Strip	1
	1756038	Hood Decal (2)	1	51	1751874	Fender Decal (1)	1
13	1747670	Hood Decal R.H. (1)	1	52	1744051BOW	Hood Assembly	1
	1756037	Hood Decal R.H. (2)	1	53	1744570	Service Instrument Decal (1)	1
14	1747671	Hood Decal L.H. (1)	1		1755934	Service Instrument Decal (2)	1
	1756036	Hood Decal L.H. (2)	1	54	1747662	Side Cover Decal (1)	2
15	1754863	R.H. Fender Decal (3114) (1)	1	55	1107381	Flat Washer 1/4	4
	1754867	R.H. Fender Decal (3018) (1)	1	56	1750686	Instrument Panel	1
	1754624	R.H. Fender Decal (3018) (2)	1	57	1750669	Throttle Decal (1)	1
16	1754862	L.H. Fender Decal (3114) (1)	1		1753413	Throttle Decal (2)	1
	1754866	L.H. Fender Decal (3018) (1)	1	58	1747144	Cap (3114)	1
	1756176	L.H. Fender Decal (3018) (2)	1	59	1750779	Ignition Switch Decal (1)	1
17	1186391	Flange Nut 5/16-18	15		1754521	Ignition Switch Decal (2)	1
18	1756041	Side Cover Decal L.H. (2)	1	60	1750671	Choke Decal (1)	1
	1756042	Side Cover Decal R.H. (2)	1		1754604	Choke Decal (2)	1
19	1756034	Decal, Model (3114) (2)	2	61	1754126	Retainer (2)	2
	1756035	Decal, Model (3018) (2)	2	62	1742934	Angle Bracket Speed Nut	4
20	1743987BOW	Running Board Support	1	63	1750532	Nut, Self Thd	6
21	1751805BOW	R.H. Running Board	1	64	1754415BDG	Spacer Plate	2
22	1751803BOW	L.H. Running Board	1	65	1754614	Seal	2
23	1742665	R.H. Foot Pad	1	66	1755779	Bearing (2)	4
24	1742664	L.H. Foot Pad (1)	1	67	1185257	Retaining Ring (2)	2
	1755729	L.H. Foot Pad (2)	1	68	1755622	Rod (2)	1
25	1186330	Fl. Lock Screw 5/16-18 x 7/8	12	69	1755620STB	Support Assembly (2)	1
26	1742666	Center Foot Pad (1)	1	70	1756466STB	Pivot Bracket (2)	1
	1755944	Center Foot Pad (2)	1	71	1736098	Carr. Bolt 5/16-18 x 5/8 (2)	2
27	1750326	Instruction Decal (1)	1	72	1755449	Ext. Spring (2)	2
	1755942	Instruction Decal (2)	1	73	1701055	Washer (2)	2
28	1750937	Operating Instrument Decal (1)	1	74	1186347	Fl. Screw 3/8-16 x 1 (2)	2
29	1750873	Quadrant	1	75	1186393	Fl. Nut 3/8-16 (2)	2
30	1111599	Hex Hd. Screw 1/4-20 x 5/8	4	76	1754519	Decal, Fuel (2)	1
31	1747836	Retaining Ring	6	77	1706782	Washer, Wave (2)	2
32	1742459BDG	Hinge Link	2	78	1705793	Washer, Nylon (2)	2
33	1758587BDG	Hinge Strap Assembly	2	79	1754125	Shoulder Bolt (2)	2
34	1752914BDG	Grille Support Assembly	2	80	1756043	Logo (2)	1
35	1734398	Lock Nut 1/4-20	8	NI	1735223	Spray Paint (White)	
36	1742458BDG	Hinge Link	2	NI	1736796	Spray Paint (Dark Green)	
37	1186309	Flange Lock Screw 1/4-20 x 5/8	12				

• Common Hardware - Purchase Locally

(1) Serial Number 0100101 thru 0199999

(2) Serial Number 0200101 thru 0299999

SUBURBAN TRACTOR



FRAME, LIFT AND
STEERING ASSEMBLY

A-5


Models 3018G AND 3114G

REF. NO.	PART NO.	DESCRIPTION	QTY. REQ.	REF. NO.	PART NO.	DESCRIPTION	QTY. REQ.
1	1724491	Thd Form Screw 5/16-18 x 3/4 ...	4	37	1730375	Shim Washer	6
2	1747804	Steering Wheel (3018)	1	38	1747303	Flange Bearing	1
	1727284	Steering Wheel (3114)	1	39	1750594	Steering Support Assembly	1
3	1185279	Roll Pin 1/4 x 2-1/4	1	40	1715301	Thrust Washer	1
4	1185632	Flange Bearing	1	41	1750501	Sector Gear Assembly	1
5	1752363	Steering Shaft Support (1)	1	42	1185386	Flange Bearing	2
	1756608	Steering Shaft Support (2)	1	43	1113527	Retaining Ring	1
6	1186389	Flange Nut 1/4-20	9	44	1747316BDG	Bracket	1
7	1186309	Flange Screw 1/4-20 x 5/8	13	45	1750581	Steering Arm	1
8	1758724BDG	Instr. Panel Supp.	1	46	1100049	Hex Head Screw 3/8-16 x 2-1/4	2
9	1185456	U Type Speed Nut 1/4-20	4	47	1733398	Hex Lock Nut 3/8-16	4
10	1742172	Battery Support (1)	1	48	1708755	Flat Washer 3/8	4
	1756073BDG	Battery Support (2)	1	49	1110150	Lock Nut 3/8-24	2
11	1754179	Push Link	1	50	1716180	Ball Joint	2
12	1736931	Handle Grip (1)	1	51	1186247	Jam Hex Nut 1/2-20	2
	1753519	Handle Grip (2)	1	52	1750499	Steering Rod	1
13	1759450BDG	Lift Lever Ass'y	1	53	1185803	Grease Fitting	1
14	1186330	Fl. Lock Screw 5/16-18 x 7/8	31	54	1750811BDG	Attachment Bracket	1
15	1750957	Lock Nut 1/2-20	2	55	1186345	Flange Hex Screw 3/8-16 x 3/4	4
16	1750495	Steering Arm	1	56	1186393	Flange Hex Nut 3/18-16	4
17	1805368	Washer	1	57	1110112	Lock Hex Nut 5/8-11	1
18	1185427	Retaining Ring	2	58	1744453	Hex Hd. Screw 5/8-11 x 2-1/4	1
19	1747189	Pin	1	59	1750486	L.H. Spindle Ass'y	1
20	1751067	Sliding Guide	1	60	1750490	R.H. Spindle Ass'y	1
21	1751069	Lift Guide	1	61	1750341	Bushing	4
22	1107385	Flat Washer 1/2	2	62	1718086	Valve Stem	2
23	1186391	Flange Lock Nut 5/16-18	41	63	1185976	Grease Fitting	4
24	1100350	Cotter Pin 1/8 x 1	2	64	1750924	Wheel (Incl. Ref. 61 & 63)	2
25	1751070	Lift Rod	1	65	1750354	Tire 15 x 6.00-6	2
26	1751715BDG	Bracket	2	66	1742133	Flange Bearing	4
27	1752414	Lift Shaft Ass'y. (1)	1	67	1185388	Retaining Ring	4
	1754950	Lift Shaft Ass'y. (2)	1	68	1701447	Washer	A/R
28	1743430	Fender Support Ass'y (1)	1	69	1750494	Front Axle Ass'y	1
	1754944BDG	Fender Support Ass'y (2)	1	70	1750841	Tie Rod	1
29	1749801BDG	Rear Panel Ass'y	1	71	1742343BOW	Front Frame	1
30	1740984BDG	Axle Support	1	72	1744013	Lift Decal (1)	1
31	1185388	Retaining Ring	2	73	1744444	Wheel Cap	2
32	1747315BDG	Bracket	1	74	1185830	Special Washer	A/R
33	1177567	Retaining Ring	1	75	1747320	Cable Guide	2
34	1751802	Rear Frame (1)	1	76	1100043	Hex Screw 3/8-16 x 1-1/4	2
	1755847BDG	Rear Frame (2)	1	77	1862273	Pulley (1)	2
35	1742934	Angle Bracket Speed Nut	4		1756177	Pulley (2)	2
36	1751284	Steering Shaft	1	78	1747322	Spacer	2

• Common Hardware-Purchase Locally (Grade 5 where applicable)

(1) Serial Number 0100101 thru 0199999
(2) Serial Number 0200101 thru 0299999

SUBURBAN TRACTOR



ENGINE ASSEMBLY

Models 3018G AND 3114G

REF. NO.	PART NO.	DESCRIPTION	QTY. REQ.	REF. NO.	PART NO.	DESCRIPTION	QTY. REQ.
1	1744390	Fuel Tank Pad	1	22	1745366	Cable Hanger	3
2	1747733	Fuel Tank Gauge (1)	1	23	1743683	Street Elbow, 45°	1
	1756044	Fuel Gauge (2)	1	24	1743685	Pipe Nipple	1
3	1747537	Fuel Tank (Incl. Ref. 2) (1)	1	25	1743684	Elbow, 90°	1
4	1752795	Fuel Line	1	26	1744455	Special Washer	1
5	1750687	Hose Clamp	2	27	1100244	Lock Washer 7/16	1
6	1751477	Fuel Shut Off Valve	1	28	1754563BDG	L.H. Heat Shield	1
7	1738433	Bushing	1	29	1744454	Hex Screw 7/16-20 x 3	1
8	1736314	Knob (1)	2	30	1185986	Speed Nut #10-24	5
	1737118	Knob (2)	2	31	1186389	Fl. Nut 1/4-20	2
9	1743511	Throttle Control (1)	1	32	1186307	Fl. Screw 1/4-20 x 3/8	4
	1755904	Throttle Control (2)	1	33	1111606	Screw, 5/16-18 x 2	1
10	1743512	Choke Control (1)	1	34	1100799	Hex Hed. Screw 5/16-18 x 1-1/2	3
	1755903	Choke Control (2)	1	35	1748146	Sq. Key 1/4 X 1-1/2	1
11	1115815	Phil. Hd. Screw #10-24 x 5/8	8	36	1747148	Sheave	1
12	1185985	Keps Nut #10-24	4	37	1755341	Electric Clutch	1
13	1752882BDG	Heat Shield	1	38	1754787	Clutch Retainer	1
14	1727491	Fuel Filter	1	39	1100255	Flat Washer, 5/16	1
15	1754578BDG	Heat Shield	1	40	1110645	Lock Washer 5/16	1
16		Engine, B&S 14 H.P. Model 400707-1205	1	41	1754612	Trim	1
		Engine, B&S 18 H.P. Model 422707-1206	1	42	1754887	Exhaust Pipe	1
17	1186230	Hex Nut 5/16-18	4	43	1185712	Thd. Cut Screw 10-24 x 1/2	4
18	1100242	Lock Washer 5/16	4	44	1754564BDG	R.H. Heat Shield	1
19	1732137	Sealing Strip	1	45	1756385	Fuel Tank (Incl. Ref. 45)	1
20	1735531	Wire Tie	5				
21	1747738	J-Clip	2				


(1) Serial Number 0100101 thru 0199999

(2) Serial Number 0200101 thru 0299999

Order Parts from your local Briggs & Stratton engine dealer.

Common Hardware - Purchase Locally (Grade 5 where applicable).

SUBURBAN TRACTOR



BRAKE AND CLUTCH ASSEMBLY

Models 3018G AND 3114G


REF. NO.	PART NO.	DESCRIPTION	QTY. REQ.	REF. NO.	PART NO.	DESCRIPTION	QTY. REQ.
1	1744269	Knob (1)	1	38	1733398	Lock Nut 3/8-16	3
	1724231	Knob (2)	1	39	1748491	Pivot	1
2	1107382	Flat Washer 5/16	1	40	1751880	Arm Ass'y	2
3	1705092	Flat Washer	2	42	1750542	Shift Lever Ass'y (1)	1
4	1111609	Hex Hd. Screw 5/16-18 x 2-3/4	4		1756047	Shift Lever Ass'y (2)	1
5	1107383	Flat Washer 3/8	9	43	1752523	Shift Rod	1
6	1747186	Push on Cap	1	44	1728908	Compression Spring	1
7	1747188	V-Belt (96.88)	1	45	1107386	Flat Washer 5/8	2
8	1752798	Belt Guide Rod	1	46	1715538	Nylon Bushing	2
9	1750297	Belt Guide	1	47	1751809	Torsion Spring	1
10	1185596	Set Screw	2	48	1746941BDG	Idler Arm Ass'y	1
11	1743640	Transmission Sheave	1	49	1726660	Idler	1
12		5-Speed Transmission Model 801	1	50	1725555	Belt Guide	2
13	1104335	Sq. Key 3/16 x 2	2	51	1100049	Hex Hd Screw 3/8-16 x 2-1/4	1
14	1100255	Flat Washer 5/16	8	52	1100243	Lock Washer 3/8	1
15	1732499	Lock Nut 5/16-18	4	53	1749764	Idler (1)	1
16	1742103BDG	Transmission Support	1		1756151	Idler (2)	1
17	1186330	FI Lock Screw 5/16-18 x 7/8	3	54	1742054	Spacer	2
18	1186391	FI Nut 5/16-18	7	55	1750352	Tire 20 x 8.00-10	2
19	1724491	Thd. Form Screw 5/16-18 x 3/4	2	56	1718086	Valve Stem	2
20	1746943	Brake Rod	1	57	1750351	Wheel Disc	2
21	1751808	Idler Support Ass'y	1	58	1747998	Washer 3/4	AR
22	1750526	Torsion Spring	1	59	1185388	Retaining Ring	2
23	1743606	Transmission Arm	1	60	1728694	Foot Rest	1
24	1107381	Flat Washer 1/4	1	61	1751882	Brake Pedal Ass'y (1)	1
25	1100241	Lock Nut 1/4	1		1756049	Brake Pedal Ass'y (2)	1
26	1111683	Hex Screw 1/4-28 x 1/2	1	62	1100350	Cotter Pin 1/8 x 1	3
27	1750946	Pin	1	63	1714233	Nylon Bushing	4
28	1705093	Washer	A/R	64	1110149	Jam Nut 5/16-24	1
29	1750539	Shaft Ass'y	1	65	1751063	Brake Lock Rod	1
30	1104436	Woodruff Key 3/16 x 3/4	1	66	1100359	Cotter Pin 1/8 x 5/8	7
31	1750299	Shift Arm Ass'y	1	67	1746942	Clutch Rod	1
32	1186244	Lock Nut 5/16-24	1	68	1893445	Washer, Flat 3/8	1
33	1752524	Ball Joint	1	69	1100086	Screw Hex Hd 3/8-16 x 1-3/4	1
34	1120210	Roll Pin 3/16 x 1.00	3	70	1747873	Wheel Cap	2
35	1186389	FI Lock Nut 1/4-20	4	71	1713783	Spacer	1
36	1744320	Belt Guide	1	72	1749904	Eye Bolt	1
37	1743985	Belt Guide	2	73	1177567	Retaining Ring (2)	1
				74	1729482	Ext. Spring (2)	1
				75	1755584BDG	Interlock Bracket (2)	1

• Common Hardware - Purchase Locally (Grade 5 where applicable)


(1) Serial Number 0100101 thru 0199999

(2) Serial Number 0200101 thru 0299999

SUBURBAN TRACTOR



Models 3018G AND 3114G




REF. NO.	PART NO.	DESCRIPTION	QTY. REQ.	REF. NO.	PART NO.	DESCRIPTION	QTY. REQ.
1	1737454	Wear Strip (1)	1	25	1752134	Console Wire Harness	1
2	1722732	Battery Cable (Pos.) (1)	1	26	1747738	J-Clip	3
	1756074	Battery Cable (Pos.) (2)	1	27	1100089	Hex Screw 1/4-20 x 2-1/2 (1)	1
3	1186389	Flange Lock Nut 1/4-20	4	28	1735265	Pivot Block (1)	1
4	1744021BDG	Light Support	1	29	1733576	Switch Seal (1)	1
5	1726435	Headlight	2	30	1752135	Interlock Harness (1)	1
6	1744489	Diode Ass'y (1)	1		1756076	Interlock Harness (2)	1
	1755616	Diode Ass'y (2)	1	31	1750976	PTO Switch (1)	1
7	1742658	Switch (1)	2		1754608	PTO Switch (2)	1
8	1735531	Wire Tie	3	32	1751496	Light Switch (1)	1
9	1744386	Battery Cable (Neg.) (1)	1		1754856	Light Switch (2)	1
	1756075	Battery Cable (Neg.) (2)	1	33	1754250	Ignition Switch	1
10	1752516	Lense (1)	1	34	1753986	Ignition Key	2
	1755910	Lense (2)	1	35	1752136	Harness, Engine	1
11	1748719	Hour Meter (3018)	1	36	1739631	Cover (1)	1
12	1744580	Seal Strip (1)	1		1755802	Cover (2)	1
13	1107381	Flat Washer 1/4	2	37	1751572	Bulb	3
14	1734398	Hex Lock Nut 1/4-20	4	38	1186020	Thd Cut Screw 6-32 x 3/8	1
15	1742173	J-Bolt, Short (1)	2	39	1743516	Replacement Fuse, 30A	1
	1752586	J-Bolt, Long (2)	2	40	1752809	Grommet	1
16	1115815	Phil. Hd. Screw #10-24 x 5/8	4	41	1752132	Voltage Sensor (3018)	1
17	1185985	Nut #10-24	4	42	1100241	Lock Washer 1/4 (2)	2
18	1751498	Battery (1)	1	43	1755487	Grommet (2)	1
	1752840	Battery (2)	1	44	1734934	Grommet (2)	1
19	1752137	Solenoid	1	46	1751328	Switch	1
20	1750963	Screw 6-32 x 1/2	4	47	1755349	Screw 1/4-20 x 1/2	2
21	1744022	Retainer	2	48	1756630	Rubber Pad (2)	1
22	1186230	Hex Nut 5/16-18	1	49	1186229	Hex Nut 1/4-20 (2)	2
23	1748014	Grommet	2	50	1111599	Hex Screw 1/4-20 x 5/8 (2)	2
24	1722081	Starter Cable	1	51	1752506	Switch	1

• Common Hardware—Purchase Locally


(1) Serial Number 0100101 thru 0199999

(2) Serial Number 0200101 thru 0299999

WIRING DIAGRAM



SUBURBAN TRACTOR



PEERLESS TRANSAXLE MODELS: 801-046

Models 3018G AND 3114G

ORDER ALL PEERLESS PARTS FROM YOUR NEAREST
POWER PRODUCTS TECUMSEH ENGINE DEALER

REF. NO.	PART NO.	DESCRIPTION
1	770071A	Transaxle Case
2	778136	Spur Gear (15 Teeth)
2A	778145	Spur Gear (12 Teeth)
3	778126A	Spur Gear (20 Teeth)
4	778127A	Spur Gear (25 Teeth)
5	778163	Spur Gear (31 Teeth)
6	778162	Spur Gear (19 Teeth)
7	778123A	Spur Gear (25 Teeth)
8	778124A	Spur Gear (30 Teeth)
9	778122A	Spur Gear (22 Teeth)
10	778128A	Spur Gear (28 Teeth)
11	778146A	Spur Gear (37 Teeth)
12	778154	Bevel Gear (42 Teeth)
13	784266	Shift Collar
14	786060	Sprocket (14 Teeth)
15	786061	Sprocket (10 Teeth)
16	776204	Counter Shaft
17	778153	Input Bevel Pinion
18	786074	Spacer
19	778138	Output Pinion
20	778139	Output Gear
21	790003	Brake Disk
22	792089A	Key
25	788040	Retaining Ring
26	780105A	Flanged Bushing
27	780118A	Flanged Bushing
28	786062A	Roller Chain (No. 41 Chain, 22 Links)
29	780072	Thrust Washer
30	780122	Needle Bearing
31	792077	Steel Ball
32	780109	Thrust Washer
33	792078	Set Screw 3/8-16 x 3/8
34	792079	Spring
35	792073	Hex Hd. Thread Forming Screw, 1/4-20 x 1-1/4
36	780108	Thrust Washer
37	780121	Ball Bearing

REF. NO.	PART NO.	DESCRIPTION
38	780113	Flat Washer
39	780119	Ball Bearing
41	788051	Square Cut Ring
42	788057	Square Cut Ring
43	780112	Needle Bearing
44	780114	Flat Washer
46	788053	Square Cut Ring
47	772082	Transaxle Cover
48	784290	Shift Rod & Fork Assembly
49	776226	Input Shaft
50	776183A	Brake Shaft
51	790007	Brake Pad Plate
52	790006	Brake Pad
53	786026	Dowel Pin
54	792075	Locknut 5/16-24
55	792076	Flat Washer
56	790031	Brake Lever
57	792073	Hex Hd. Thread Forming Screw, 1/4-20 x 1-1/4
58	790025	Brake Pad Holder
59	778053A	Differential Gear Assembly (Incl. 1 of No. 60)
60	780064	Bushing
60A	780120	Bushing
61	778166	Bevel Gear
62	778131	Bevel Pinion
63	786034	Drive Pin
64	780065	Thrust Washer
65	792018	Retaining Ring
66	792040	Roll Pin
67	780001	Thrust Washer
68	774670	Axle (15-1/8" Long)
69	774669	Axle (13-3/16" Long)
70	792035	Retaining Ring
71	792074	Hex Hd. Plug 9/16-18 Thread
73	786086	Bracket
74	788069	Seal Square Cut