


SUBURBAN TRACTOR



BODY WORK AND TRIM ASSEMBLY






MODEL 3018, 3114 AND 3212

REF. NO.	PART NO.	DESCRIPTION	NO. REQ'D
1	1747835	Seat (3212 - 3114)	1
	1747834	Seat (3018)	1
2 •	1186130	Rd. Hd. Sq. Neck Screw 3/8- 16 x 1-1/4	1
3	1743434	Seat Support Assembly	1
4	1733960	Compression Spring	1
5	1735125	Nut & Washer Assembly	1
6 •	1107383	Flat Washer 3/8	2
7	1734269	Knob	2
8	1735265	Pivot Block	2
9 •	1107382	Flat Washer 5/16	2
10 •	1100799	Hex Screw 5/16-18 x 1-1/2	2
11	1742810	Rear Fender	1
12	1747663	Hood Decal	1
13	1747670	Hood Decal R.H.	1
14	1747671	Hood Decal L.H.	1
15	1753878	Fender Decal R.H. (3018)	1
	1754865	Fender Decal R.H. (3114)	1
	1753990	Fender Decal R.H. (3212)	1
16	1753879	Fender Decal L.H. (3018)	1
	1754864	Fender Decal L.H. (3114)	1
	1753989	Fender Decal L.H. (3212)	1
17 •	1186391	Flange Nut 5/16-18	7
18 •	1100242	Lock Washer 5/16	2
19 •	1186230	Hex Nut 5/16-18	2
20	1743987	Running Board Support	1
21	1751805	R.H. Running Board	1
22	1751803	L.H. Running Board	1
23	1742665	R.H. Foot Pad	1
24	1742664	L.H. Foot Pad	1
25 •	1186330	FL. Lock Screw 5/16-18 x 7/8	9
26	1742666	Center Foot Pad	1
27	1750325	Instruction Decal	1
28	1750938	Operating Instrument Decal	1
29	1754415	Spacer, Plate	2
30 •	1111599	Hex Hd. Screw 1/4-20 x 5/8	4

REF. NO.	PART NO.	DESCRIPTION	NO. REQ'D
31	1747836	Retaining Ring	6
32	1742459	Hinge Link	2
33	1744062	Hinge Strap Assembly	2
34	1752914	Grille Support Assembly	2
35	1734398	Lock Nut 1/4-20	8
36	1742458	Hinge Link	2
37 •	1186309	Flange Lock Screw 1/4-20 x 5/8	12
38 •	1186389	Flange Lock Nut 1/4-20	12
39	1742493	Grille Cap	2
40 •	1100069	Hex Hd. Screw 1/4-20 x 1	2
41	1742494	Grille	1
42	1743566	Side Cover Guide	4
43 •	1186059	Pop Rivet 1/8 x 1/4	8
44	1743554	L.H. Side Cover	1
	1743553	R.H. Side Cover	1
45	1744065	Sealing Block (3018 - 3114) ...	2
46 •	1115815	Phil. Hd. Machine Screw #10- 24 x 5/8	4
47	1727127	Rubber Latch	2
48	1727126	Clip	2
49	1185985	Keps Nut #10-24	2
50	1744067	Sealing Strip (3018 - 3114) ...	1
51	1751874	Fender Decal	1
52	1744051	Hood Assembly	1
53	1744570	Service Instrument Decal	1
54	1747662	Side Cover Decal	2
55 •	1107381	Flat Washer 1/4	4
56	1750686	Instrument Panel	1
57	1750669	Throttle Decal	1
58	1747144	Cap (3114 - 3212)	2
59	1750779	Decal, Ignition	1
60	1750671	Choke Decal (3018 - 3014) ...	1
	1752794	Choke Decal (3212)	1
61	1742934	Angle Speed Nut	4
62	1754614	Strip, Seal (3018 - 3114)	2
63	1744013	Decal, Lift (3212)	1

- Common Hardware - Purchase Locally (Grade 5 where applicable)

SUBURBAN TRACTOR



FRAME, LIFT AND STEERING ASSEMBLY


MODEL 3018, 3114 AND 3212

REF. NO.	PART NO.	DESCRIPTION	NO. REQ'D
1	1724491	Thd Screw 5/16-18 x 3/4	4
2	1747804	Steering Wheel (3018)	1
	1727284	Steering Wheel (3114 - 3212)	1
3 •	1185279	Roll Pin 1/4 x 2-1/4	1
4	1185632	Flange Bearing	1
5	1752363	Steering Shaft Support	1
6 •	1186389	Flange Nut 1/4-20	13
7 •	1186309	Flange Screw 1/4-20 x 5/8	17
8	1754928	Instr. Panel Support (3018)	1
	1752880	Instr. Panel Support (3114-3212)	1
9	1185456	U Type Speed Nut 1/4-20	4
10	1742172	Battery Support	1
11	1732198	Hook	1
12	1736931	Handle Grip	1
13	1185830	Flat Washer	4
14 •	1186330	Flange Lock Screw 5/16-18 x 7/8	38
15	1750957	Lock Jam Nut 1/2-20	2
16	1750495	Steering Arm	1
17	1805368	Washer	1
18	1185427	Retaining Ring	2
19	1747189	Pin	1
20 •	1107382	Flat Washer, 5/16	2
21 •	1100359	Cotter Pin 1/8 x 5/8	1
22 •	1107385	Flat Washer 1/2	2
23 •	1186391	Flange Lock Nut 5/16-18	42
24 •	1100350	Cotter Pin 1/8 x 1	2
25	1751070	Lift Rod	1
26	1185803	Grease Fitting	1
27	1752414	Lift Shaft Assembly	1
28	1743430	Fender Support Assembly	1
29	1749801	Rear Panel Assembly	1
30	1740984	Axle Support	2
31	1749028	Lift Lever Assembly	1
32	1185388	Retaining Ring	2
33	1177567	Retaining Ring	3
34	1751802	Rear Frame	1
35	1742934	Angle Bracket Speed Nut	4
36	1751284	Steering Shaft	1
37	1730375	Shim Washer	3
38	1747303	Flange Bearing	1
39	1750594	Steering Support Assembly	1
40	1715301	Thrust Washer	1
41	1750501	Sector Gear Assembly	1
42	1185386	Flange Bearing	2
43	1113527	Retaining Ring	1
44	1747315	Bracket	1
45	1750581	Spindle Arm Assembly	1
46 •	1100049	Hex Head Screw 3/8-16 x 2-1/4	2

REF. NO.	PART NO.	DESCRIPTION	NO. REQ'D
47 •	1733398	Hex Lock Nut 3/8-16	4
48 •	1708755	Flat Washer 3/8	4
49	1110150	Lock Nut 3/8-24	4
50	1716180	Ball Joint	2
51	1186247	Jam Hex Nut 1/20	2
52	1750499	Steering Rod	1
53	1747316	Bracket	1
54	1750811	Attachment Bracket	1
55 •	1186345	Flange Hex Screw 3/8-16 x 3/4	4
56 •	1186393	Flange Hex Nut 3/18-16	4
57	1110112	Lock Hex Nut 5/8-11	1
58	1744453	Hex Hd. Screw 5/8-11 x 2-1/4	1
59	1750486	L.H. Spindle Assembly	1
60	1750490	R.H. Spindle Assembly	1
61	1720327	Bushing	4
62	1718086	Valve Stem	2
63	1185976	Grease Fitting	4
64	1750924	Wheel (Incl. Ref. 61 & 63)	2
65	1750354	Tire 15 x 6.00-6	2
66	1742133	Flange Bearing	4
67	1185388	Retaining Ring	4
68	1701447	Washer	A/R
69	1750494	Front Axle Assembly	1
70	1750841	Tire Rod	1
71	1742343	Front Frame	1
72	1744013	Lift Decal	1
73	1744444	Wheel Cap	2
74	1185830	Special Washer	A/R
75	1747320	Cable Guide	2
76 •	1100043	Hex Screw 3/8-16 x 1-1/4	2
77	1862273	Pulley	2
78	1747322	Spacer	2
79	1751715	Bracket	2
80	1754179	Push Link	1
81	1751067	Sliding Guide	1
82	1751069	Stationary Guide	1
83	1751781	Lift Shaft Ass'y	1
84	1705093	Flat Washer	5
85	1751798	Flange Bearing	2
86 •	1100360	Cotter Pin 3/16 x 1	1
87	1751787	Lift Handle Ass'y	1
88	1751795	Handle	1
89	1751796	Bearing	1
90	1751797	Thrust Bearing	1
91	1751791	Arm Ass'y	1
92	1750957	Lock Nut 1/2-20	1
93 •	1107383	Flat Washer 3/8	1
94	1751794	Lift Link Ass'y	1

• Common Hardware - Purchase Locally

SUBURBAN TRACTOR



MODEL 3018, 3114 AND 3212

REF. NO.	PART NO.	DESCRIPTION	NO. REQ'D
1	1744390	Fuel Tank Pad	1
2	1747733	Fuel Tank Gauge	1
3	1747537	Fuel Tank (Incl. Ref. 2)	1
4	1752795	Fuel Line	1
5	1750687	Hose Clamp	2
6	1751477	Fuel Shut Off Valve	1
7	1738433	Bushing	1
8	1736314	Knob	2
9	1743511	Throttle Control (A) (B)	1
	1744070	Throttle Control (C)	1
10	1743512	Choke Control (A) (B)	1
	1744071	Choke Control (C)	1
11 •	1115815	Phil. Hd. Screw #10-24 x 5/8	8
12 •	1185985	Keps Nut #10-24	4
13	1752882	Heat Shield (A) (B)	1
14	1727491	Fuel Filter	1
15	1754578	Heat Shield (A) (B)	1
16		Engine, B & S 12 H.P. Model 281707 (3212)	1
		Engine, B & S 14 H.P. Model 400707 (3114)	1
		Engine, B & S 18 H.P. Model 422707 (3018)	1
17 •	1186230	Hex Nut 5/16-18	4
18 •	1100242	Lock Washer 5/16	4
19	1732137	Sealing Strip (A) (B)	1
20	1735531	Wire Tie	5
21	1747738	J-Clip	3
22	1745366	Cable Hanger (A) (B)	3
23	1743683	Street Elbow, 45° (A) (B)	1
24	1743685	Pipe Nipple (A) (B)	1
25	1743684	Elbow, 90°	1
26	1744455	Special Washer	1
27 •	1100244	Lock Washer 7/16	1
28	1754887	Exhaust Pipe (A) (B)	1


REF. NO.	PART NO.	DESCRIPTION	NO. REQ'D
29	1744454	Hex Screw 7/16-20 x 3	1
30	1185986	Speed Nut #10-24	8
31	1754612	Trim (A) (B)	1
32	1185712	Self Thd. Scw. 10-24 x 1/2 (A) (B)	4
33 •	1111606	Screw, Hex Hd. 5/16-18 x 2	1
34 •	1100799	Hex Hd. Screw 5/16-18 x 1 1/2	3
35	1748146	Sq. Key 1/4 x 2-1/2	1
36	1742535	Sheave	1
37	1755341	Electric Clutch	1
38	1754787	Clutch Retainer	1
39 •	1100255	Flat Washer 5/16	1
40 •	1110645	Lock Washer 5/16	1
41	1748014	Grommet	1
42	1752883	Heat Shield (C)	1
43	1752910	Heat Shield (C)	1
44 •	1186309	Fl. Screw 1/4-20 x 5/8 (C)	3
45 •	1186009	Screw 10-16 x 1/2 (C)	1
46	1752909	Heat Shield (C)	1
47	1752890	Muffler (C)	1
48	1752911	Heat Shield (C)	1
49	1755340	Spacer (C)	1
50 •	1100241	Lock Washer 1/4 (C)	1
51 •	1100069	Hex Hd. Screw 1/4-20 x 1 (C)	1
52	1747993	Sock. Hd. Screw 5/16-18 x 3/4 (C)	2
53	1185140	Lock Washer, Spec. (C)	2
54	1752912	Elbow, 90° (C)	1
55 •	1186330	Fl. Screw 5/16-18 x 7/8 (C)	1
56 •	1186307	Fl. Screw 1/4-20 x 3/8 (A) (B)	4
57 •	1186389	Fl. Nut 1/4-20 (A) (B)	2
58	1754564	R.H. Heat Shield (A) (B)	1
59	1754563	L.H. Heat Shield (A) (B)	1
60	1750962	Screw 10-24 x 5/8	4

• Common Hardware - Purchase Locally (Grade 5 where applicable)

• Order Parts from your local Briggs & Stratton Engine Dealer

(A) - 3018
(B) - 3114
(C) - 3212

SUBURBAN TRACTOR



HYDROSTATIC & BRAKE ASSEMBLY


MODEL 3018, 3114 AND 3212

REF. NO.	PART NO.	DESCRIPTION	NO. REQ'D	REF. NO.	PART NO.	DESCRIPTION	NO. REQ'D
1	1743639	Pedal Assembly	1	52	1741994	Eaton Hydrostatic Transmission Model 7	1
2	• 1120210	Roll Pin 3/16 x 13/16	1	53	• 1111614	Hex Hd. Screw 3/8-16 x 3	4
3	1185802	Flange Bushing	2	54	1100905	Woodruff Key 1/8 x 1/2	2
4	1743693	Hydro Pedal Support	1	55	1747166	Set Screw 1/4-28 x 3/8	3
5	• 1107386	Flat Washer 5/8	1	56	1744089	Hydro Sheave	1
6	1741857	Accelerator Shaft Assembly	1	57	1741953	Fan	1
7	1110150	Lock Hex Nut 3/8-24	1	58	• 1111599	Hex Screw 1/4-20 x 5/8	1
8	1733963	Ball Joint	1	59	• 1100241	Lock Washer 1/4	1
9	1741866	Speed Control Rod	1	60	• 1107381	Flat Washer 1/4	1
10	• 1100049	Hex Hd. Screw 3/8-16 x 2-1/4	1	61	• 1100242	Lock Washer 5/16	3
11	• 1107383	Flat Washer 3/8	10	62	1754637	Idler	1
12	1741334	V-Belt 84.5"	1	63	1751812	Idler Arm	1
13	• 1733398	Lock Nut 3/8-16	6	64	1701322	Extension Spring	1
14	1749904	Special Pivot	1	65	1724929	Thrust Washer	2
15	1714233	Snap Bushing	2	66	1728030	Sleeve	1
16	1751820	Cam Plate Rod	1	67	• 1186331	Fl. Screw 5/16-18 x 1	1
17	1751881	Cam Plate Arm Ass'y	1	68	• 1734514	Lock Nut 1/2-13	1
18	1720612	Extension Spring	1	69	• 1107385	Flat Washer 1/2	1
19	• 1100360	Cotter Pin 3/16 x 1	1	70	• 1186330	Flange Lock Screw 5/16-18 x 7/8	5
20	1728908	Compression Spring	1	71	• 1186381	Flange Lock Nut 5/16-18	2
21	1746944	Brake Rod	1	72	1741867	Bracket	1
22	1120210	Roll Pin 3/16 x 13/16	2	73	1747186	Push On Cap	1
23	1751880	Arm Assembly	1	74	1741859	Neutral Plate	1
24	1751063	Brake Lock Rod	1	75	1732369	Spacer	1
27	1751882	Brake Pedal Assembly	1	76	1703052	Special Washer	1
28	• 1100350	Cotter Pin 1/8 x 1	2	77	1741872	Neutral Plate Support	1
29	1728694	Foot Rest	1	78	1741873	Neutral Plate Bracket	1
30	• 1100359	Cotter Pin 1/8 x 5/8	5	79	1742332	Lever	1
31	1118802	Retaining Ring	2	80	• 1186231	Hex Nut 3/8-16	1
32	1741851	Control Pin	1	81	• 1100255	Flat Washer 5/16	3
33	1720699	Cushion Block	1	82	• 1100255	Flat Washer 5/16	5
34	1720928	Extension Spring	2	83	• 1732499	Lock Nut 5/16-18	5
35	1743386	Speed Control Arm	1	84	• 1186345	Flange Screw 3/8-16 x 3/4	3
36	1720361	Thrust Washer	2	85	1720706	Bearing	1
37	1720523	Neutralizing Arm	2	86	1743638	Hydro Pedal Pad	1
38	1720529	Thrust Washer	1	87	1749764	Idler	1
39	1185732	Retaining Ring	1	88	1747875	Grip	1
40	• 1186309	Flange Lock Screw 1/4-20 x 5/8	1	89	1713783	Spacer	1
41	• 1186389	Flange Lock Nut 1/4-20	1	90	1747873	Cap	2
42	1744566	Retaining Ring	2	91	• 1100256	Flat Washer 3/8	2
43	1747872	Washer	A/R	92	1748491	Pivot Block	1
44	1750352	Tire 20-8.00 x 10	2	93	• 1186230	Hex Nut 5/16-18	3
45	1718086	Valve Stem	2	94	• 1100242	Lock Washer 5/16	3
46	1750350	Wheel Disc	2	95	• 1100062	Hex Screw 3/8-16 x 2-1/2	1
47	1747874	U-Bolt	2	96	1751811	Bracket	1
48	1748146	Square Key 1/4 x 2-1/2	2	97	1741195	Washer	2
49	1719694	Clamp Saddle	2	98	1705093	Washer, 1/32 Thk	A/R
50	•	Transaxle, Peerless Model 1327B (See breakdown page 10)	1	99	1705092	Washer, 3/32 Thk	A/R
51	1720720	Gasket	1	100	• 1100243	Lock Nut 1/4	4

• Common Hardware - Purchase Locally (Grade 5 where applicable)

• Order parts from your local Tecumseh Power Products Engine Dealer

SUBURBAN TRACTOR




Model 1327B

ORDER ALL PEERLESS PARTS FROM YOUR NEAREST
POWER PRODUCTS TECUMSEH ENGINE DEALER

REF. NO.	PART NO.	DESCRIPTION
1	778197	Bevel Pinion
2	778198	Bevel Gear
3	786019	Drive Pin
4	786027	Drive Block
5	774028A	Differential Carrier
6	774029A	Differential Carrier
7	776033A	Ring Gear
8	774526	Axle (13-11/64" long)
9	774527	Axle (15-11/64" long)
10	780107	Washer
11	780042	Thrust Washer
12	792018	Snap Ring
13	792020	Hex Hd. Screw, 1/4-20 x 2-1/4
14	792006	Lockwasher 1/4"
15	770072	Case Assembly (Incl. Nos. 16 & 17)
16	780013	Needle Bearing
17	780088	Needle Bearing
18	772085	Cover Assembly (Incl. Nos. 16 & 19)
19	780089	Needle Bearing
20	782041A	Housing and Bushing Assembly (8-5/8" long) (Incl. 2 of No. 21)
21	780054	Bushing



REF. NO.	PART NO.	DESCRIPTION
22	782042A	Housing and Bushing Assembly (8-5/8" long) (Incl. 2 of No. 21)
23	776207	Brake Shaft
24	788044	Case-to-Cover Gasket
25	778036	Output Gear
26	778083	Idler Gear
27	778041	Output Shaft
28	786017	Spacer
29	780001	Washer
30	780090	Washer
31	788008	Oil Seal
32	786026	Dowel Pin
33	792048	Hex Washer Hd. Screw, Thread Forming, 1/4-20 x 1
34	792010	Pipe Plug
35	788046	Gasket
36	790027	Brake Disk
37	790006	Brake Pad
38	790007	Brake Pad Plate
39	790005	Brake Pad Holder
40	790031	Brake Lever
41	792076	Flat Washer
42	792075	Locknut 5/16-24
43	792073	Hex Hd. Screw, Thread Forming, 1/4-20 x 1-1/4



WIRING DIAGRAM




WIRE COLOR CODE

R-RED	R/W-RED/WHITE
B-BLACK	Y/B-YELLOW/BLACK
W-WHITE	R/B-RED/BLACK
O-ORANGE	W/BL-WHITE/BLUE
Y-YELLOW	R/Y-RED/YELLOW
P-PURPLE	BR-BROWN
BL-BLUE	





MODEL 3018 & 3114 SHOWN
MODEL 3212 SIMILAR



REF. NO.	PART NO.	DESCRIPTION	NO. REQ'D
1	1737454	Wear Strip	1
2	1722732	Battery Cable (Pos.)	1
3 •	1186389	Fl. Lock Nut 1/4-20 (A) (B)	4
4	1744021	Light Support (A) (B)	1
5	1726435	Headlight (A) (B)	2
6	1744489	Diode Ass'y (A) (B)	1
	1752420	Diode Ass'y (C)	1
7	1742658	Switch	2
8	1735531	Wire Tie	3
9	1744386	Battery Cable (Neg.)	1
10	1752516	Lense	1
11	1748719	Hour Meter (3018)	1
12	1751328	Interlock Switch	1
13 •	1107381	Flat Washer 1/4	2
14	1734398	Hex Lock Nut 1/4-20	4
15	1742173	J-Bolt	2
16 •	1115815	Phil. Hd. Screw #10-24 x 5/8	2
17	1185985	Nut #10-24	2
18	1751498	Battery	1
19	1752137	Solenoid	1
20	1750963	Screw 6-32 x 1/2	4
21	1744022	Retainer (A) (B)	2
22 •	1186230	Hex Nut 5/16-18	1

REF. NO.	PART NO.	DESCRIPTION	NO. REQ'D
23	1748014	Grommet	2
24	1722081	Starter Cable (A) (B)	1
	1741506	Starter Cable (C)	1
25	1752134	Console Wiring Harness	1
26	1747738	J-Clip	3
27 •	1100089	Hex Screw 1/4-20 x 2-1/2	1
28	1735265	Pivot Block	1
29	1733576	Switch Seal	1
30	1752135	Interlock Harriess	1
31	1750976	PTO Switch	1
32	1751496	Light Switch (A) (B)	1
33	1754250	Ignition Switch	1
34	1753986	Ignition Key	2
35	1752136	Harness, Engine (A) (B)	1
	1752421	Harness, Engine (C)	1
36	1739631	Cover	1
37	1751572	Bulb	3
38	1186020	Thd. Cut Screw 6-32 x 3/8	1
39	1743516	Replacement Fuse, 30A	1
40	1752809	Grommet	1
41	1752132	Voltage Sensor (3018)	1
42	1755169	Harness, Cruise (3018)	1

• Common Hardware - Purchase Locally

(A) Model 3018
(B) Model 3114
(C) Model 3212